

# TRINER SCALE

## Rate Chip Installation

### Instructions For:

Scale Model      Part No.

SPS-70    } .....RC016  
TAN-70    }

SPS-150 } .....RC011  
TAN-150 }  
MG-150  }

### To install your new Rate Chip:

1. Turn the scale off and unplug the AC adapter from the wall outlet. If the scale is connected to a remote device, unplug that connection also.
2. The rate chip compartment is located on the right side of the scale. If equipped with a Security Plate, remove the two screws and set the plate aside. Use a small flat head screw driver and gently pry open the plastic Rate Chip Compartment Cover.

3. Remove the Rate Chip card by grasping the edges and pulling straight out.
4. Insert the new Rate Chip card. Make sure the card is fully inserted into the slot (the rate card can only be installed in one direction. If it does not fit properly, turn it over and reinsert).
5. Replace the Rate Chip Compartment Cover and if needed, the Security Plate.
6. Reconnect the AC adapter.
8. Your scale is now ready for use with its new, updated rates.

Triner Scale & Mfg. Co., Inc.  
8411 Hacks Cross Road  
Olive Branch, MS 38654-4010  
TEL: 1-662-890-2385 or  
1-800-238-0152

